



CORALIFE®

HIGH PERFORMANCE AQUARIUM LIGHTING

CIRCULATION PUMP SUCTION CUP INSTALLATION

STEP 1



Clean glass/acrylic surface using an algae scraper to ensure that all algae and debris is removed from the area in which the pump will be located.

STEP 2



After attaching pump to suction cup, firmly push in on lever to release suction cup from plastic base.

STEP 3



Place suction cup in clean area and press suction cup into place by firmly pushing in on lever to expel excess air from suction cup.

STEP 4



Flip the locking lever down while continuing to apply inward pressure on the suction cup.